

© CONTENTS ©

Chapter 1. INTRODUCTION

1.1 Features	1-1
--------------	-----

Chapter 2. SPECIFICATIONS

2.1 General Specifications	2-1
2.2 Performance Specifications	2-2
2.3 Names of Parts and Functions	2-3
2.4 PID Control Action	2-4
2.4.1 Processing Type	2-4
1) Velocity Type Processing	2-4
2) Measured Value Derivative Type (Pre-Derivative Type)	2-4
2.4.2 Control Actions	2-5
1) Proportional Action (P Action)	2-5
2) Integral Action (I Action)	2-7
3) Derivative Action (D Action)	2-9
4) PID Action	2-10
5) PID Processing Expression	2-10
6) Forward/Reverse Actions	2-11

Chapter 3. INSTALLATION

3.1 Installation Ambience	3-1
3.2 Handling Precautions	3-1

Chapter 4. TROUBLESHOOTING

4.1	Errors Indicated by RUN LED Flickering	4-1
4.2	Troubleshooting Procedure	4-1
4.2.1	RUN LED Flickering	4-1
4.2.2	RUN LED Off	4-1
4.2.3	Unreadable Processing Result of PID Control Module	4-2
4.2.4	Run LED of Enabled Loops Off	4-2
4.2.5	PID Control Module Hardware Defect	4-2

Chapter 5. DIMENSIONS

5.1	G3F-PIDA Dimensions	5-1
5.2	G4F-PIDA Dimensions	5-2

Chapter 6. FUNCTION BLOCK

6.1	Insertion of the Function Blocks for PID Control Module on the GMWIN	6-1
6.2	Function Blocks	6-2
6.2.1	Module Initialization (G3F-PIDA:PID5INI, G4F-PIDA:PID3INI)	6-2
6.2.2	Manipulated Value(MV) Reading (Array Type) (G3F-PIDA:PID5ARD, G4F-PIDA:PID3ARD)	6-3
6.2.3	Manipulated Value(MV) Reading (Single Type) (G3F-PIDA : PID5RD, G4F-PIDA : PID3RD)	6-4
6.3	Errors on Function Block`	6-5

Chapter 7. PROGRAMMING

7.1	A Program for Controlling an Electric Furnace (with Applying the A/D Conversion Module, PID Control Module and D/A Conversion Module)	7-1
7.2	A Program for Control Using a RTD (Resistance Temperature Detector) (with Applying the RTD Input Module, PID Control Module and D/A Conversion Module)	7-6
7.3	A Program for Control Using a Thermocouple (with Applying the TC Input Module, PID Control Module and D/A Conversion Module)	7-10