

Table of Contents

Section	Page
<hr/> Chapter. 1 <hr/>	
1-1. System Requirements for PMU MASTER Installation	1-2
1-2. Cable Standards for Communications with PMU Series	1-3
1-3. Installing PMU MASTER	1-5
1-3-1 PMU Master Installation Order	1-5
1-4. PMU MASTER Structure	1-9
1-5. PMU MASTER Creation Method	1-10
<hr/> Chapter. 2 <hr/>	
2-1. PMU Series System Structure and Equipment Summary	2-1
2-1-1. System Structure	2-1
2-1-2. System Structure Equipment Summary	2-2
2-2. PMU MASTER Screen Menu and Contents	2-3
2-2-1. Project Manager	2-3
2-2-2. Screen Editor	2-4
2-2-3. Message Editor	2-5
2-2-4. Symbol Editor	2-5
2-2-5. Alarm Editor	2-6
2-2-6. Link Editor	2-6
<hr/> Chapter 3. Project Manager Setup and Function <hr/>	
3-1. File (F)	3-4
3-1-1. Change PMU Type	3-5
3-1-2 Open Edit Screen	3-6
3-1-3. Open Project File	3-7
3-1-4. Make Project File	3-9
3-1-5. Save as ...	3-11
3-1-6. Extract Project File	3-13
3-1-7. Exit	3-15
3-2. Edit	3-16
3-2-1. Select File	3-17
3-2-2. Select All	3-18
3-2-3. Select Cancel	3-19
3-2-4. Cancel All	3-20
3-2-5. Add File	3-21
3-2-6. Delete File	3-22
3-3. View	3-23
3-3-1. View File	3-24
3-3-2. View Project File	3-25
3-3-3. Project File Information	3-26
3-3-4. File Information.	3-27
3-3-5. Refresh	3-31
3-4. Communication	3-32
3-4-1. Send Project File	3-33

3-4-2. Receive Project File	3-34
3-4-3. Send Link File	3-35
3-4-4. Receive Link File	3-36
3-4-5. Receive Alarm File(This operation is available in PMU200, 300)	3-37
3-4-6. Select Communications Port	3-38
3-5. Editing Tools	3-39
3-5-1. Screen Editor (S)	3-39
3-5-2. Symbol Editor (Y)	3-40
3-5-3. Message Editor (M)	3-41
3-5-4. Alarm Editor (A)	3-42
3-5-5. Link Editor (L)	3-43
3-6. Window (W)	3-44
3-6-1. Cascade (C)	3-44
3-6-2. Tile (T)	3-45
3-6-3. Arrange Icons	3-46
3-6-4. Close All (A)	3-47

Chapter 4. Screen Editor Setup and Function

4-1. File	4-3
4-2. Draw	4-6
4-3. Edit	4-12
4-4. Tag Enter	4-20
4-5. Tag Edit	4-23
4-6. Others	4-24
4-7. Simulation	4-26
4-8. Zoom	4-33
4-9. About Edit Tools	4-34.

Chapter 5. Message Editor Setup and Functions

5.1 File	5-2
5.2 Edit	5-4
5.3 Search	5-6

Chapter 6. Symbol Editor Setup and Function

6-1 File(F)	6-2
6-2 Draw	6-5
6-3. Edit	6-6
6-4. Adjust Screen	6-7
6-5. Zoom Screen	6-9

Chapter 7 Alarm Editor Setup and Functions

7-1. File	7-2
7-2. Edit	7-4
7-3. Search	7-6
7-4 Alarm History	7-7

Chapter 8. Link Editor Setup and Functions

8-1. PMU and PLC Communication Method	8-4
8-2. File	8-6
8-3. Link Editor	8-7

Chapter 9. Tag Register and Other Functions

9-1. N TAG (Numeric Tag)	9-1
9-2. T TAG (Touch Tag)	9-9
9-3. F TAG (Function Key Tag)	9-17
9-4. W TAG (Buffer Write Tag)	9-26
9-5. A TAG (Auxiliary Tag)	9-32
9-6. S TAG (Symbol Tag)	9-37
9-7. B TAG (Block Tag)	9-44
9-8. D TAG (Delay Tag)	9-46
9-9. C TAG (Operation Tag)	9-52
9-10. M TAG (Message Tag)	9-57
9-11. I Tag (Precision Adjust Tag)	9-63
9-12. J TAG (Move Tag)	9-69
9-13. R TAG (Territory Move Tag)	9-73
9-14. P TAG (Pie Graph Tag)	9-78
9-15. E Tag (Statistic graph Tag)	9-83
9-16. G TAG (Level Graph Tag)	9-86
9-17. K Tag (Key Tag)	9-92
9-18. V TAG (Key Display Tag)	9-95
9-19. X TAG (Trend graph Tag)	9-104
9-20. L TAG (Lamp Tag)	9-110
9-21. Q TAG (String Tag)	9-115
9-22. W TAG (Window Tag)	9-120