


AppendixC. Structure of GMWIN Menu

A Structure of GMWIN Menu is as follows.



Online(O)
Connect+Write+Run+Monitor On
Connect
Disconnect
Read
Write
Monitor
Mode Change
Data Clear
Reset
Flash Memory
Link Enable
PLC Info
I/O info ...
I/O Forcing
Link Info
Comm info ...
Mnet Parameter
Mnet info ...
I/O Skip
Fault Mask ...
Initialize Special Modules...
Start Online Edit
Write for Online Edit
Cencel Online Edit

Window(W)
Cascade
Tile Horizontally
Tile Vertically
Arrange Icons
Close All

Monitor Off
Variable Monitor
I/O Monitor
Time Chart Monitor
Link Parameter Monitor

System Info ...
Error/Warning Info ...
AC Fail History ...
Error History
Mode Change History ...
I/O Module Fault info ...

Run
Stop
Pause
Debug
Master Change

Flash Memory Type ...
Falsh Memory Write ...

Input
Output
Enable I/O Forcing ...

Debug(D)
Debug Eng
Go
Step Over
Step Into
Step Out
Pause
Run to Cursor
Add/Remove BreakPoint
Breakpoint List/Condition ...
Task Enabel...

Window(H)
Contents
How to Use Help
About GMWIN